

INSTRUCTIONS

All the parts:-

1. The lite shooter; a yellow box with five holes on the top.
2. The wire; coming out of the lite shooter.
3. The battrey; a little blue "Ever Ready". To be fixed on loped end of wire
4. The trigger; a papper clip. To be fassend on a round steel thing with holes
5. The shooting place; a little box contrey names and things. With a stick
6. The refiller; box like one above, butwith no stick and firing list
7. The second refiller; big box with screw on top.
8. The firers; a box which isfull of them. The smallest box there is

How to oprate:-

First finde the light shooter anthe firers. ~~Put~~ thefirers ino the holes in the top. Then get the end which has not got the loop init. Fassen the thing at the end onto the steel thing with holeson. Put it so that the one ont topwill go through one of the holes and meet the other one at the bottom. After you have done that get the papper clip and fassen it on any where. Nexed set the shooting place up, put it to the place you want it to fire to where everyou want it to go to. Before letting the first light go remeber to fix the battrey on. First stand it (the battrey) up, Then finde looped end ofthe wire add fassen it on on the top. When the batrey is fixed, and every thing is ready just take the papper clip off and—— the first one has gon! After firering tate the screw out of refiller and squeeze top w-ken let into the other little box(it must be put in at the side slit). T-ake firers out of the lit- shes and drop them in the same thing and s ame place as you did with the screw .Put your hand over the plave and shake the box. After some time put the box upside down and shake the fireres out of the slit in the top, and the fireres can be used again.